



Magna Lock installation

The Magna Latch is a BOCA approved child safety latch. The purpose of this lock is to make it difficult (if not impossible) for small children to enter the swimming pool area unaccompanied by an adult. We recommend this latch for all gates going around a swimming pool irrespective of your particular local pool code requirements.

If you live in an area which follows strict BOCA compliance, you **MUST** have a Magna Latch for each gate going around a swimming pool. If you're not sure, check with your Homeowner's Association or the city you live in. Ask them about: Pool Fencing Restrictions.

Magna Latches have the ability to be installed ABOVE the actual height of your gate...if you like. This is important for Boca Swimming Pool jurisdictions because most require that the top of the lock (release mechanism location) is 54" high from the ground.

One choice for Boca pool code fencing is our Style 9: Storrs with 2 horizontal rails at 48" high. This is a BOCA compliant pool configuration. When choosing this option, you can install the Magna Lock on each gate where the vertical rod and release mechanism extend above the gate 6" to meet the 54" high requirement referenced above.



MAGNA·LATCH®

For swimming and other child safety gates, most safety standards specify the following minimum height requirements above the finished ground/fixing surface:

1) latch release knob 'F' at minimum 54"-59" (1370-1500mm); 2) fence height of between 4' & 6' (1200 & 1820mm)

Always confirm these and other requirements with the appropriate pool or safety authorities in your area and install this latch in accordance with the local fence/barrier codes and regulations. Also, pool gate must open outward, away from the pool, so this latch must be fitted to the *outside* of a pool gate. **Tools:** Electric and cordless drills, drill bits, Phillips No. 2 screwdriver (hand & powered types). Note: If mounting to steel or vinyl with aluminum or steel inserts, it is advisable to pre-drill the holes to prevent screw breakage.

Installation Procedure

1. The gap between gate frame and latch post must be between $\frac{3}{8}$ " (10mm) and $1\frac{1}{16}$ " (37mm); $\frac{3}{4}$ " (19mm) is ideal.

2. Determine the location of the hole for Mounting Bracket 'A' by measuring up from the finished ground/fixing surface...
 • for 54" knob height measure up $36\frac{3}{8}$ " (925mm); • for 59" knob height measure up $41\frac{3}{8}$ " (1050mm).

Place Mounting Bracket 'A' on the post as shown, and, using one of the 1" (25mm) wafer-head, self-drilling screws, fix the bracket to the post – through the side fixing hole. Now install two more of these screws through the front of the bracket.

3. To install Mounting Bracket 'B' measure up from Bracket 'A' $13\frac{3}{8}$ " (340mm). Mark this point and fix as '2' above.
 NOTE: For 4 feet (1200mm) fences without an extra-high post, this measurement should be 5" (125mm) for 54" knob height and 10" (250mm) for 59" knob height.

Place the Bracket 'B' so that the holes are centered on the marked line. Fix bracket using the same screws as per Bracket 'A'. (NOTE: In some applications it may be necessary to add a spacer to clear a post cap. Spacers S1, S2 & S3 are for this purpose and should be inserted behind the mounting brackets during installation.)

4. Take the main LATCH BODY 'C' and slide it down onto the Mounting Bracket 'B', ensuring the rear track of the latch slides over brackets 'B', then 'A'.

5. Slide the Latch Body until the bottom of the latch aligns neatly with the lower end of Bracket 'A' (see dashed line 'L'). Take the single $\frac{3}{8}$ " (10mm) countersunk screw 'H' and secure the Latch Body – DO NOT use a power or cordless drill – to Bracket 'A'.

6. The final part to be installed is the STRIKER BODY 'D'. Note that the Striker Body slides on a dovetail track within the Mounting Plate (P1, P2) and is operated by an internal adjustment screw; NEVER use a powered drill to adjust this screw.


See Diagram 'E'. Locate the Striker Body assembly onto the post as shown. Position the Striker Body to obtain a $\frac{1}{8}$ " (3mm) gap between the lower part of the latch and the top of the Striker Body as shown. Maintain this gap and fix two 1" (25mm) screws through the two main holes of the Striker Body. The two, small (cylindrical) dress plugs supplied should now be pressed into the screw holes.

7. a) Open the gate and secure two more screws through the side leg of the Mounting Plate. Note: If the width of the gate frame is $1\frac{1}{2}$ " (38mm) or greater, follow step b)...


b) With the gate open, adjust the Striker Body using the screwdriver in the adjustment screw. Turn counter-clockwise until the two holes are exposed, as in Diagram 'E'. Fix the two remaining screws to secure the Mounting Plate.

8. Use the screwdriver to adjust the Striker Body to align with the Latch Body, as shown in Diagram 'E'. Open and close the gate to check the latch operates correctly. Adjust as necessary at any time after installation to ensure safe operation of the latch.

NOTE: Future vertical adjustment of the latch can be achieved by removing the screw 'H', sliding the Latch Body up or down the post to obtain correct operational alignment, then inserting the screw into the appropriate hole.



Another optional configuration is our Style 9: Storrs 54" high fence/gate with 3 horizontal rails. Here you can install the lock with the top of the vertical rod extending just above each gate. Style 9: Storrs:



2 horizontal rails



3 horizontal rails



In addition to its magnetic locking feature, the Magna Lock includes the ability to fully lock your gate with an included key.